

DB

-

-30

B

*

Without directional valve
= No code
With built-in directional spool valve
= W

Pilot operated valve (complete) = No code
Pilot operated valve without main spool assembly (do not enter nom. size) = C
Pilot operated valve with main spool assembly (enter valve size 10 or 30) = C
* C without main valve

Nominal Size	Ordering details	
	Subplate mounting	Pipe connection
8	—	8 (M18 × 1.5 or G3/8")
10	10	10 (M22 × 1.5 or G1/2")
15	—	15 (M27 × 2 or G3/4")
20	20	20 (M33 × 2 or G1")
25	—	25 (M42 × 2 or G1 1/4")
32	30	30 (M48 × 2 or G1 1/2")

Normally closed = A
Normally open = B

For subplate mounting = No code
For threaded connection = G

Adjustment elements
Rotary knob = 1
Sleeve with hexagon and protective cap = 2
Lockable rotary knob with scale = 3

Series 30 to 39 (30 to 39:
unchanged installation and connection dimensions) =30

Further details in clear text

No code = mineral oils
V = phosphate ester

No code = British
2 = metric

Z4 = Plug-in connector
Z5 = Large Plug-in connector
Z5L = Large Plug-in connector with light

No code= Without hand override
N= With hand override

W220-50 = 220V 50Hz AC
G24 = 24 V DC
W220R=Solenoid commutating automatically 220V AC

No code =Valve for minimum cracking pressure 0.5MPa
U = Valve for minimum cracking pressure 0.25MPa

No code = Pilot fluid feed internal ,return internal
X = Poilt fluid feed external,return internal
Y = Poilt fluid feed internal,return external
XY = Poilt fluid feed external,return external

100= Settable pressure up to 10.0 MPa
315= Settable pressure up to 31.5 MPa

B= Technology of Beijing Huade Hydraulic